



# Panasonic KX-TGA600M Battery Replacement

Remove and replace the dead battery in your Panasonic KXTGA-600M.

Written By: Marc Jeannott



## INTRODUCTION

In this guide we will cover how to completely replace the battery component of your Panasonic KX-TGA600M.

## Step 1 — Battery



- On the back of the phone, remove battery cover.
- Push down on the marked indentation and pull downwards.

## Step 2



- Pull out to remove the battery.

To reassemble your device, follow these instructions in reverse order.

